

BLIND/TOWER ASSEMBLY

(BLIND AND TOWER MUST BE COMPLETE AT THIS POINT)

YOU WILL NEED BLOCKS FOR LEVELING WHILE ATTACHING

1. POSITION BLIND ON SIDE WITH DOOR FACE OUTWARD.
2. LAY TOWER ON SIDE WITH PORCH MATCHING DOOR OF BLIND. (YOU WILL
LAY NEED TO USE BLOCKS TO HOLD BLIND AND TOWER LEVEL.
3. INSERT 1 WASHER ON BOLT AND INSERT THRU PREDRILLED HOLE FROM
INSIDE OF BLIND THRU TOWER. (INSTALLING FROM INSIDE BLIND IS EASIER,
WITH SOMEONE ASSISTING OUTSIDE.)
4. ATTACH CHAIN LINKS, WASHER AND NUT TO BOLT.
5. REPEAT IN EACH HOLE UNTIL FINISHED.
6. ERECT BLIND AND TOWER BY ATTACHING ROPE OR CABLE AROUND TOP OF 2
LEGS AT TOWER BASE. STAND BY USING TRUCK OR HOIST.
7. ATTACH STAIRWAY IN SLOTS ON PORCH.
8. CHAIN LINKS ARE USED FOR ANCHORING BLIND/TOWER.

*(ALL TOWERS AND BLINDS MUST BE TIED OR ANCHORED DOWN)
SUPERIOR FIBERGLASS OR REPRESENTATIVES ARE NOT RESPONSIBLE FOR
INSTALLATION OF BLINDS AND TOWERS.*

PARTS LIST: (ENCLOSED IN TOWER KIT) (4) CHAIN LOOPS, (4) 2 1/2" X 3/8" BOLTS, (8)
WASHERS, (4) 3/8" NUTS

ALL TOWERS AND BLINDS MUST BE TIED OR ANCHORED DOWN

SUPERIOR FIBERGLASS OR REPRESENTATIVES ARE NOT

RESPONSIBLE FOR INSTALLATION OF BLINDS AND TOWERS

CONTACT YOUR DEALER FOR TOWER ANCHOR KITS